

# MAINTENANCE: EFFORT MECHANISM

To guarantee a long life for our fastening clamps, it is essential to make a preventive maintenance, depending on the aggressiveness of the environment.



1

## DISMANTLING

Dismantle both lateral covers.



2

## CLEANING BLOWING

In order to free any foreign particle, project compressed air in all directions on the hole and in different positions of the arm.



3

## LUBRICATION

Spray on the hole with a lubricant for bearings in different positions of the arm.



4

## ASSEMBLY

Put both covers on the clamp.